


Installation guide – Spare parts and accessories

Overhaul kit | Code number 027F0678
PMFH, size 80-6



| | | | | | |
|--|--|--|---|---|--|
| <p>1</p> <p>Alu.</p> <p>Ø26 mm Ø1.02"</p> <p>Total no. = 1</p> | <p>2</p> <p>Fibre</p> <p>Ø33 mm Ø1.28"</p> <p>Total no. = 4</p> | <p>3</p> <p>Ø9 mm Ø0.36"</p> <p>Total no. = 3</p> | <p>4</p> <p>Alu.</p> <p>Ø18 mm Ø0.70"</p> <p>Total no. = 1</p> | <p>5</p> <p>Alu.</p> <p>Ø14 mm Ø0.55"</p> <p>Total no. = 1</p> | <p>6</p> <p>Fibre</p> <p>Ø75 mm Ø2.95"</p> <p>Total no. = 1</p> |
| <p>7</p> <p>Fibre</p> <p>Ø39 mm Ø1.54"</p> <p>Total no. = 2</p> | <p>8</p> <p>Fibre</p> <p>Ø60 mm Ø2.36"</p> <p>Total no. = 1</p> | <p>9*</p> <p>Alu.</p> <p>Ø32 mm Ø1.26"</p> <p>Total no. = 1</p> | <p>10*</p> <p>Alu.</p> <p>Ø22 mm Ø0.87"</p> <p>Total no. = 1</p> | <p>16</p> | <p>17</p> <p>Ø50 mm Ø1.97"</p> |
| <p>18</p> <p>Ø18 mm Ø0.71"</p> | <p>21</p> <p>Standard</p> <p>Ø28 mm Ø1.10"</p> <p>Total no. = 1</p> <p>Weak</p> <p>Ø27 mm Ø1.06"</p> <p>Total no. = 1</p> | <p>23</p> <p>M39</p> | <p>24</p> <p>Ø23 mm Ø0.91"</p> | | |

* The spare part is included in the package but is not used for PMFH size 80-6.