


Installation Guide

Overhaul kit

PMFL, size 80-5 | Code number 027F0634

027R9893

027R9893



| | | | | | |
|---|---|---|--|--|---|
| <p>1</p> <p>Alu.</p> <p>Total no. = 1</p> | <p>2</p> <p>Fibre</p> <p>Total no. = 4</p> | <p>3</p> <p>Total no. = 3</p> | <p>4</p> <p>Alu.</p> <p>Total no. = 1</p> | <p>5</p> <p>Alu.</p> <p>Total no. = 1</p> | <p>6</p> <p>Fibre</p> <p>Total no. = 1</p> |
| <p>7</p> <p>Fibre</p> <p>Total no. = 2</p> | <p>8</p> <p>Fibre</p> <p>Total no. = 1</p> | <p>9*</p> <p>Alu.</p> <p>Total no. = 1</p> | <p>10*</p> <p>Alu.</p> <p>Total no. = 1</p> | <p>16</p> | <p>17</p> |
| <p>18</p> | <p>21 Standard</p> <p>1 set</p> | | | | |

* The spare part is included in the package but is not used for PMFL size 80-5.

For identification and installation of Weak and Strong spring sets please see Installation guide DKRCI.PI.GE1.C