


Installation guide – Spare parts and accessories

Overhaul kit | Code number 027F0677
PMFH, size 80-5



| | | | | | |
|---|--|---|--|--|---|
| <p>1</p> <p>— = Alu.</p> <p>Total no. = 1</p> | <p>2</p> <p>— = Fibre</p> <p>Total no. = 4</p> | <p>3</p> <p>Total no. = 3</p> | <p>4</p> <p>— = Alu.</p> <p>Total no. = 1</p> | <p>5</p> <p>— = Alu.</p> <p>Total no. = 1</p> | <p>6</p> <p>— = Fibre</p> <p>Total no. = 1</p> |
| <p>7</p> <p>— = Fibre</p> <p>Total no. = 2</p> | <p>8</p> <p>— = Fibre</p> <p>Total no. = 1</p> | <p>9*</p> <p>— = Alu.</p> <p>Total no. = 1</p> | <p>10*</p> <p>— = Alu.</p> <p>Total no. = 1</p> | <p>16</p> | <p>17</p> |
| <p>18</p> | <p>21</p> <p>Standard</p> <p>Total no. = 1</p> <p>Weak</p> <p>Total no. = 1</p> | <p>23</p> | <p>24</p> | | |

* The spare part is included in the package but is not used for PMFH size 80-5.