



REFRIGERATION AND
AIR CONDITIONING

Instructions

Analog output module


AK-OB 110




080R9267




RI8MH253



Montage / Assembly / Einbau / Montaje



Tilslutning / Connection / Anschluß / Raccordement / Conexión



| | Modul Module Módulo | Punkt Point Punto | Type Typ Tipo | Max |
|-----|---------------------------|-------------------------|---------------------|--------|
| AO1 | 1 | 24 | 0 - 10 V | 2.5 mA |
| AO2 | 1 | 25 | 0 - 10 V | 2.5 mA |

